



LIST OF SPARES

| Item | Description | Pack | R2610 | R2683 R2806 |
|------|----------------------|------|-------|----------------|
| 1 | Front Bogie Complete | 1 | X9810 | X9835 |
| 2 | Coupling Pack | pack | X9056 | X9056 |
| 3 | Motor + Worm | 1 | X9647 | X9647 |
| 4 | Motor Retainer | pack | X9649 | X9649 |
| 5 | Loco Chassis Bottom | pack | X9648 | X9648 |
| 6 | Loco Contacts | pack | X9650 | X9650 |
| 7 | Loco Wheel Set | set | X9811 | X9836 |
| 8 | Drawbar | pack | X8629 | X8629 |
| 9 | Pcb Socket + Pins | 1+1 | X9084 | X9084 |
| 10 | Tender Wheel Set | set | X9652 | X9652 |
| 11 | Tyres Pack | 10 | X9812 | X9812 |