



LIST OF SPARES

Item No.	Description	Pack	R30399SS	R30401	R30455	R30560SS	R30472SS	R30477
1	Cylinder block	1	X7187	X7187	R30455/01	R30455/01	X7187	X7187
2	Motor flywheel	1+1	X7188	X7188	X7188	X7188	X7188	X7188
3	Universal joint worm cover	set	X7189	X7189	X7189	X7189	X7189	X7189
4	Gears & cover plate	set	X7190	X7190	X7190	X7190	X7190	X7190
5	Motion bracket valve gear etc.	set	X7191	X7191	X7191	X7191	X7191	X7191
6	Loco wheel set	set	R30399/06	X7192	X7192	R30399/06	R30472/06	R30477/06
7	Loco chassis bottom contacts	pack	X50290	X50290	X50290	X50290	X50290	X50290
8	Loco chassis contact pin	1	X7194	X7194	X7194	X7194	X7194	X7194
9	Bogie assy bracket screw/nut	pack	X7195	X7205	X7205	X7209	X7205	R30477/09
10	Tender chassis	1	R30399/10	R30401/10	R30455/10	R30560/10	R30472/10	R30401/10
11	Tender wheel set	set	X7197	X7204	X7204	X7197	X7204	X7204
12	Tender chassis bottom	1	X7198	X7198	X7198	X7198	R3716/12	X7198
13	Main PCB & blanking plug	set	X50259	X50259	X50259	X50259	X50259	X50259
14	Contact pins tender	1	X7200	X7200	X7200	X7200	X7200	X7200
15	Rear pony assembly	1	X7201	X50291	R30455/15	X7201	X50291	X50291
16	Steam generator	1	X50241	N/A	N/A	X50241	X50241	N/A
17	NEM Couplings & pocket	10	X9289	X9289	X9289	X9289	X9289	X9289
18	Loco to tender connector	1	X50242	X50260	X50260	X50242	X50242	X50260
19	Transducer PCB	1	X50003	N/A	N/A	X50003	X50003	N/A
20	Photointerrupter	1	X50066	N/A	N/A	X50066	X50066	N/A
NI	Accessory pack	1	X8001	X8003	X8003	X16732	X8003	X14236