



**LIST OF SPARES**

Item No.	Description	Pack	R2099A/B/C, R2183A/B	R2527
1	Coupling Rod Set	1	X8581	X8581
2	Driving Wheel / Axle set	1	X8579	X8579W
3	Loco Chassis Bottom with Screws, Contact Wires	1	X8583	X8583
4	Tender Frame	1	X8318	X8318W
5	Bogie Assembly includes Spring, Seat Screw	1	X8718	X8718
6	Buffer Beam	1	X8316	X8316W
7	Ringfield Plate (includes Gear Axle & Bearing)	1	X8321	X8321
8	Gear Set	set	X8320	X8320
9	Drawbar	pack	X8716	X8716
10	Tender Base Plate and Screws	1	X8322	X8322
11	Tender Wheel Set	set	X8303	X8303W
12	Traction Tyres	10	X8331	X8331
13	Armature	1	X8304	X8304
14	Ringfield Carbon Brush	10	X8328	X8328
15	Ringfield Brush Spring	10	X8329	X8329
16	Coupling & Retainer	2 + 2	X8052	X8052
17	Drive Unit Complete	1	X8797SK	X8797SK
18	Ringfield Brush Contacts with Capacitor and Bead	1	X8795	X8795
*	Small Parts Pack	pack	X8892	X8892