



LIST OF SPARES

Item	Description	Pack	R2522	R2523	R2764
1	Motor Two Brass Flywheels	1	X9614	X9614	X9614
2	Main PCB Board	1	X9615	X9615	X9615
3	Lights Board	1	X9616	X9616	X9616
4	Motor Support	1	X9617	X9617	X9617
5	Gear Box Cover	10	X9618	X9618	X9618
6	Drive Unit	1	X9619	X9619	N/A
6	Drive Unit (Tyres)	1	X9619M	X9619M	N/A
6	Drive Unit (Tyres)nem pocket	1	N/A	N/A	X9619MN
7	Bogies (no Wheels)	1	X9620	X9620	N/A
7	Bogies (no Wheels)nem pocket	1	N/A	N/A	X9620M
8	Worm Pinion / Shaft Assembly	2	X9621	X9621	X9621
9	Universal Shaft	10	X9622	X9622	X9622
10	Coupling Pack	10	X9623	X9623	X9623
11	Wheel Set Drive Unit	Set	X9624	X9624	N/A
11	Wheel Set Drive Unit (Tyres)	Set	X9624M	X9624M	X9624M
12	Assembly Pack	pack	X9625	X9625	X9625
13	Underframe	1	X9632	X9633	X9632
14	Snow Plough Pack (cut away)	2	X9626	X9626	X9626
15	Coupling pack nem pocket	10	X9289	X9289	X9289
	not illustrated Tyres	10	X9721	X9721	X9721