



LIST OF SPARES

Item	Description	Pack	R2742/X	R2743/X,R2844/X	R2744/X,R2815	R2745/X,R2827	R2843/X	R2845/X
1	Motor Retainers	pack	X9923	X9923	X9923	X9923	X9923	X9923
2	Motor	1	X4026	X4026	X4026	X4026	X4026	X4026
3	Cylinder Block	1	X9924	X9937	X9938	X9939	X9924	X9937
4	Valve Gear Set	set	X9925	X9925	X9925	X9925	X9925	X9925
5	Coupling Rods Set	set	X9926	X9926	X9926	X9926	X9926	X9926
6	Gear Set	set	X9940	X9940	X9940	X9940	X9940	X9940
7	Loco Wheel Set	set	X6108	X9927	X9927	X6109	X6108	X9927
8	Loco Chassis Bottom	pack	X9928	X9928	X9928	X9928	X9928	X9928
9	Bogie Assembly	1	X9970	X9929	X9929	X9974	X9970	X9923
10	Coupling Pack	10	X9289	X9289	X9289	X9289	X9289	X9289
11	Drawbar Assembly	1	X9935	X9935	X9935	X9935	X9935	X9935
12	Tender Frame Assembly	1	X9975	X9930	X9931	X9976	X9975	X9930
13	Tender Chassis Bottom	pack	X9932	X9932	X9932	X9932	X9932	X9932
14	Tender Wheel Set	set	X9971	X9934	X9977	X9933	X6129	X9934
15	Accessory Bag	pack	X6050	X6049	X6049	X6049	X6050	X6049
16	Sand Pipes	pack	X9936	X9936	X9936	X9936	X9936	X9936
17	PCB Socket + Socket	pack	X9084	X9084	X9084	X9084	X9084	X9084
18	Bogie Bracket	pack	X9941	X9941	X9941	X9941	X9941	X9941

Decoder for X versions not shown (R8249)