



LIST OF SPARES					
Item No	Description	Pack	R2782XS	R2894XS	R2989XS
1	Motor Retainers	1+1	X8847	X8847	X8847
2	Motor Assembly	1	X4026	X4026	X4026
3	Cylinder Block and Motion Bracket	1+1	X9032	X6237	X9032
4	Valve Gear Set	set	X8942	X8942	X8942
5	Gear Set	set	X8849	X8849	X8849
6	Loco Wheel Set	set	X8943	X9090	X9090
7	Loco Chassis Bottom	1	X8944	X8944	X8944
8	Bogie Assembly	1	X8968	X8968	X8968
9	Couplings Rods	set	X8429	X9093	X9093
10	Dummy Pony Truck	1	X9834	X9834	X9834
11	Draw Bar	pack	X6126	X6126	X6126
12	Tender Chassis Assembly	1	X6127	X6238	X6127
13	Tender Wheel Set	set	X8948	X8948	X8948
14	Tender Chassis Bottom with Screws	pack	X8949M	X8949M	X8949M
15	Coupling Units	pack	X9289	X9289	X9289
16	Speedo	1	X9091	X9091	X9091
17	Main PCB	1	X6101	X6101	X6101
18	Speaker	1	X9999	X9999	X9999
19	Decoder (programmed)	1	X9997	X9997	X9997
20	Tender Connection	pack	X9958	X9958	X9958
21	Loco to tender wires / plug	pack	X6113	X6113	X6113
*	Small Parts Pack	pack	X8950	X8950	X8950
*	Assy Pack	pack	X4682	X4524	X4682