



LIST OF SPARES

item no	description	pack	R2915	R2916/X	R2917/X	R3005/X
1	motor assy	1	X6199	X6199	X6199	X6199
2	cylinder block /motion bracket	pair	X6200	X6200	X6200	X6200W
3	gear set	set	X6201	X6201	X6201	X6201
4	loco wheel set	set	X6202	X6202	X6202	X6202W
5	coupling rods /valve gear set	set	X6203	X6203	X6203	X6203W
6	loco chassis bottom	1	X6204	X6204	X6204	X6204W
7	pony truck	1	X6205	X6205	X6205	X6205W
8	buffers loco	2	X6206	X6206	X6206	X6206W
9	tender chassis assy	1	X6207	X6207	X6207	X6207W
10	tender chassis bottom	1	X6208	X6208	X6208	X6208W
11	draw bar assy	1	X6170	X6170	X6170	X6170W
12	tender wheel set	set	X9359	X9359	X9359	X9359W
13	tender connection	1	X9958	X9958	X9958	X9958
14	supports	2	X6210	X6210	X6210	X6210
15	coupling pack	10	X9289	X9289	X9289	X9289W
16	pcb unit	1+1	X9084	X9084	X9084	X9084
17	buffers tender	4	X6209	X6209	X6209	X6209W
NI	assy bag	pack	X10555	X10555	X10555	X10555W
NI	electric connetion	1	X6113	X6113	X6113	X6113