



LIST OF SPARES

Item No	Description	Pack	R2918/X	R2919/X	R3006/X
1	Motor assy	1	X6199	X6199	X6199
2	Cylinder block /motion bracket	pair	X6200	X6200	X6200W
3	Gear set	set	X6201	X6201	X6201
4	Loco Wheel set	set	X6202	X6202	X6202W
5	Coupling rods /valve gear set	set	X6203	X6203	X6203W
6	Loco chassis bottom	1	X6204	X6204	X6204W
7	Pony truck	1	X6205	X6205	X6205W
8	Buffers (loco)	2	X6206	X6206	X6206W
9	Tender chassis assy	1	X6207	X6207	X6207W
10	Tender chassis bottom	1	X6208	X6208	X6208W
11	Draw bar assy	1	X6170	X6170	X6170W
12	Tender wheel set	set	X9359	X9359	X9359W
13	Tender connection	1	X9958	X9958	X9958
14	Supports	2	X6210	X6210	X6210W
15	Coupling pack	10	X9289	X9289	X9289W
16	PCB Unit	1+1	X9084	X9084	X9084
17	Buffers (tender)	4	X6209	X6209	X6209W
18	Assy bag	pack	X10555	X10555	X10555W
NI	Electric connection	1	X6113	X6113	X6113