



**LIST OF SPARES**

| Item No.        | Description    | Pack | R2902XS | R2903XS | R3036XS | R3037XS | R2977XS |
|-----------------|----------------|------|---------|---------|---------|---------|---------|
| 1               | Motor          | 1    | X9362M  | X9362M  | X9362M  | X9362M  | X9362M  |
| 2               | Gear Assembly  | pair | X9363   | X9363   | X9363   | X9363   | X9363   |
| 3               | Links          | 5    | X9364   | X9364   | X9364   | X9364   | X9364   |
| 4               | Drive Pinion   | 1    | X9365M  | X9365M  | X9365M  | X9365M  | X9365M  |
| 5               | Chassis Frame  | 1    | X9654   | X9366   | GENERIC | GENERIC | X9366   |
| 6               | Couplings Rods | set  | X9573   | X9369   | X9371   | X9573   | X9369   |
| 7               | Loco Wheel Set | set  | X9373M  | X9372M  | X9372M  | X9373M  | X9372 M |
| 8               | Chassis Bottom | 1    | X9374   | X9374   | X9374   | X9374   | X9374   |
| 9               | PCB            | 1    | X6195   | X6195   | X6195   | X6195   | X6195   |
| 10              | Collector Set  | set  | X9375   | X9375   | X9375   | X9375   | X9375   |
| 11              | Sound Decoder  | 1    | X6196   | X6196   | X6196   | X6196   | X6196   |
| 12              | Speaker        | 1    | X6197   | X6197   | X6197   | X6197   | X6197   |
| 13              | Speaker Holder | 1    | X6198   | X6198   | X6198   | X6198   | X6198   |
| not illustrated | Assembly Bag   | pack | X5410   | X5410   | X5410   | X5410   | X5410   |

**Item 5 Chassis Frame**  
 Generic Spare for Several Locomotives  
 X9654 Black Chassis Black Buffer Beam  
 X9655 Black Chassis Red Buffer Beam